

	MODEL	OCTAVE NAME	OCTAVE NUMBER	FREQUENCY (Hz)
TENOR	BTB-C3	Tenor C	C3	130.8
BASS	BTB-B2	Bass	2	123.5
	BTB-A#2	Bass	2	116.5
	BTB-A2	Bass	2	110.0
	BTB-G#2	Bass	2	103.8
	BTB-G2	Bass	2	98.0
	BTB-F#2	Bass	2	92.5
	BTB-F2	Bass	2	87.3
	BTB-E2	Bass	2	82.4
	BTB-D#2	Bass	2	77.8
	BTB-D2	Bass	2	73.4
	BTB-C#2	Bass	2	69.3
	BTB-C2	Bass C	C2	65.4
CONTRA-BASS	BTB-B1	Contra-Bass	1	61.7
	BTB-A#1	Contra-Bass	1	58.3
	BTB-A1	Contra-Bass	1	55.0
	BTB-G#1	Contra-Bass	1	51.9
	BTB-G1	Contra-Bass	1	49.0
	BTB-F#1	Contra-Bass	1	46.3
	BTB-F1	Contra-Bass	1	43.7
	BTB-E1	Contra-Bass	1	41.2
	BTB-D#1	Contra-Bass	1	38.9
	BTB-D1	Contra-Bass	1	36.7
	BTB-C#1	Contra-Bass	1	34.7
	BTB-C1	Contra-Bass C	C1	32.7

